NAME OF THE EXPERIMENT: Verification of Thevenin's Theorem.

APPARATUS REQUIRED:

Variac (250 V , 50 Hz) Voltmeter (AC) 0-600V) Ammeter (5 Amp)

Resillances - 4 nos. (,60,Ω ,40 Ωr

158 Ω, 190 Ω)

Connecting Wires

Multimeter.

THEORY:

A network with two terminals A and B can be replaced by a single voltage source V_{th} in series with a single resistance K_{th} . Where V_{th} is the open circuit voltage appearing between the terminals A and B when load has been disconnected. R_{th} is the equivalent resistance looking into the two terminals A and B with all power sources within the terminal pair removed. This is known as Thevenin's Theorem.

For the verification of Thevenin's theorem, the measurement of V_{th} , R_{th} and then the load resistance connected between A and B terminals and load current is measured.


OBSERVATION TABLE:


P 2 2	Vin' . (V)	V _{th} (V)	lsc : 3	R _{th=} V	Ι <u>.</u> (A)	(A)	ار- اِلْ (A)	% error
· American			14.7	100°		112	•	- V 3
		· ·		- An		,		· (*)
	. 1	1	4:	- Maria	Tatal			in Wild
4 / 5				18.	in y	7.	,	


PRECAUTIONS:

- 1. Connections should be tight and correct.
- 2. Variac must be adjusted properly.
- 3. Power should be off when the apparatus is not in use for taking reading, to avoid heating of apparatus.

Circuit Diagram










fig (d). The venin's Equivalent aircuit

NAME OF THE EXPERIMENT: To assign polarity of single phase transformer and make

its three phase connections.

APPARATUS REQUIRED: 1.

1. Three transformers , 1-φ

2. Voltmeter (0-600V)


3. An A.C Source

4. Connecting wires.


THEORY:

To perform polarity test of the three given transformers:

One transformer is taken at one time and the connections are made as shown in the circuit diagram. A voltage V1 is applied between the joints A1 and A2. A second voltage V2 is measured across B1 and B2. One terminal of one A1 is connected with one terminal of the other B1 and voltage across the other two terminals, V3 is measured. V3 may be the sum or difference of the voltages V1 and V2. If same polarities are connected together then V3 is equal to V1-V2 and if opposite polarities are connected together, then V3 is equal to V1-V2. Thus we can assign polarity of single phase



* Same Polarities and joined together.




V3 = V1 + V2 • Opposite Polarities in joined together.

To make the three phase connections:

The three single phase transformers are assigned polarities as explained earlier and they are connected as shown in figure. The primary windings are connected in star and secondary windings in delta connection. The primary is connected to ground neutral as shown in Figure. The ratio between secondary and primary line voltage is 1/v3 times the transformer ratio of each transformer. There is 300 phase shift between the primary and secondary line voltages which means star-delta transformer bank cannot be paralleled with either star-star or delta-delta bank. The voltages VRY, VYB, VRB and VBN are measured respectively under the Y-connection, and the line voltage and phase

voltage is taken. Similarly Vby, Vry, Vbr are measured under the delta connection. The ratio is taken which ideally should be equal to one. The values are tabulated.

CIRCUIT DIAGRAM:



OBSERVATION TABLE:

TABLE -1 (Polarity Test)

S.No	TRANSFOR-	VOLTAGE V1	VOLTAGE V2	V3= V1+V2	V3=. V1-V2
1.	T1 -		- 44	4.	The state of the s
2.	T2	F 45 1	* .		
3.	тз				

TABLE-2 (Three phase connection)

35 15	Y-connection						Δ-connection				
VRY	VYB	VRB	VBN	'VRN	VÝN	VRY/ VBN	Vry	Vyb	Vbr	Vry/Vbr	
and and			10 h	17:40	the s		1	教授	100		
1	To the	w file					A 31 18 E		Í	1/4	

27

PRECAUTIONS: 1. The three single phase transformers should not be connected arbitrarily. Polarity test must be done for any connection. 2. It is always advisable to mark the polarities on the transformer by means of chalk 3. The supply fed to primary of the transformer should never exceed the ratio of the transformer. So it is better to supply power through a three-phase Variac.

NAME OF THE EXPERIMENT: Measurement of single phase power and power factor by three voltmeter method and compare the result with

wattmeter.

APPARATUS REQUIRED:

Variac (250 V, 50 Hz)

Voltmeter - 3 nos. (AC, 300V)

Ammeter (5 Amp)

Rheostat

Load Connecting Wires

Multimeter.

THEORY:

The power consumed by the load is given by the relation:

P = V I cos φ

Where, P= input power

V = voltage across the load impedance

I = effective circuit current.

φ=phase difference between the V and I.

and cos φ= power factor

the vector diagram is shown in fig. 1 and wattmeter readings are tabulated in the observation chart.


Let, V1 = voltage drop across the combination

V2= voltage drop across the rheostat

V3= voltage drop across the rheostat load impedance.

· φ=load power factor angle.

P= power observed by the load. $P = V_S I \cos \phi$.



PROCEDURE:

First of all, connections are made as per circuit diagram

Supply was given to the circuit.

Connect the voltmeter and ammeter as shown in the figure.

Readings are to be taken for two or three times and observations were taken by adjusting the rheostat.

OBSERVATION TABLE:

S. No	(A)	V1 (V)	V2~ ·(V)	V3. (V)	W (Watt)	Mf.	WxMf (Watt).	cosф (three volt- meter)	coso (wattm -eter)	%error	VR	VL
1	1		Y. Can	1	16		1	P. Value	N. P. S. J.	1	7	1
	1.	12 ;	31	1	1.18	10	1	July "	The state of the s	first as	the state of	4 4
	-	The state of the s	1						1. 4/6 300	March 1	700	10 14
1	4	A.	1.1.2	4.7				•	Tar of		- 加	
	Barrier A	160	-				y .				W.	**************************************

CALCULATION:


From right angled triangle OCA

$$OA^2 = OC^2 + AC^2$$

or,
$$V1^2 = (OB + BC)^2 + (V3\sin\varphi)^2$$

 $V1^2 = (V2 + V3\cos\varphi)^2 + (V3\sin\varphi)^2$

And finally



PRECAUTIONS:

- 1. Connections should be made properly and tighten them.
- 2. Vs should not be greater than Va
- 3. A.C power should be disconnected just after taking the readings in order to prevent damage of the electrical instruments.

NAME OF THE EXPERIMENT: No load characteristic of a DC Shunt generator.

AIM: To obtain and plot the no-load characteristic of a DC Shunt Generator.

APPARATUS REQUIRED:

Ammeter (0-3 A)

Voltmeter (0-300V) Rheostat (290 Ω)

Tachometer (0-2000 rpm)

Connecting wires.

THEORY:

The relation between no load generated e.m.f. in armature and the field exciting current If at a given speed is given by no load characteristic.

According to the circuit diagram, Ra is the armature Rheostat of D.C motor and Rf is the field Rheostat of D.C Motor.

For a D.C Generator the voltage equation is given by

$$Eg = \frac{\varphi ZN \times P}{60 A}$$

And Eg = Va + IaRaWhere $\phi = flux$

 ϕ = flux density

Z = total number of conductors

P = no. of generator pole

A = no. of parallel paths in armature

N = speed in r.p.m


From above two equations

Eg = Ka ф

It is obvious that when If is increased from its initial value, the flux and hence generated e.m.f. increases directly as current. But as the flux density increases the poles become saturated so greater increase in If is required to produce a given increase in voltage than previous one, due to which we get the saturation in V-I characteristic.

PROCEDURE:

- 1. Connect the circuit of motor and generator as per circuit diagram.
- 2. Initially we put Rf at its maximum value and rf as well as Ra at minimum & maximum respectively.
- 3. When motor M speeds up at rated speed cut Ra to zero slowly.
- 4. We adjust the field current of the generator by rheostat, so as to obtain rated voltage at no load.
- 5. For various values of current we take the generated voltage.



OBSERVATION TABLE:

1	IN	CREASING		DECREASING					
S. No	Field current	Voltage (V)	Speed of motor, N	S. No	Field current	Voltage (V)	Speed of motor,		
1	Total .		*6.	1.	X .	-1.44			
2.	The Thirty of	4.40%	7 18 5	2.		112	a business		
-	a de la	- 150. A.	Kin .			2-783			
•		W. A.	DA Te		174				
12.	No.			12.	3	物 , 和	B 7 1		
13.	and the	my File	1. 37 .1	13.			图 数分 系		

RESULT: The open load characteristic of DC shunt generator is plotted.

From the graph we observe that initially the nature was linear and later on saturation takes place.